

Connect your Chromebook to Wi-Fi

To connect to the Internet, use a compatible Wi-Fi network.

Step 1: Turn on Wi-Fi

1. Open Chromebook.
2. At the bottom right, select the time. (see image right)
3. Select Not Connected (see image right)
Note: If you see your Wi-Fi network name and a signal strength, your Chromebook is already connected to Wi-Fi.
4. Turn on Wi-Fi.
5. Your Chromebook will automatically look for available networks and show them to you in a list.

Step 2: Pick a network and connect

1. Select the Wi-Fi network
Remember, your information might be visible to other people on this network.
2. Connect to a secure network
3. Select the secure Wi-Fi network
4. Type the network password.
5. Select Connect.

